



Kirby Morgan Dive Systems, Inc.®

1430 Jason Way Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.KirbyMorgan.com email: kmdsi@KirbyMorgan.com

Part #525-333 SuperLite® 27® Helmet Spares Kit

PART #	DESCRIPTION	QTY	PART #	DESCRIPTION	QTY
330-030	Screw	1	510-724	Low Volume Oral Nasal Mask	1
330-035	Washer	1	510-754	Head Cushion Assembly	1
510-008	O-ring*	2	515-033	Communications Set	1
510-010	O-ring*	1	520-042	Tie Wrap	1
510-029	O-ring*	1	525-309	Regulator Rebuild Kit	1
510-260	O-ring*	1	525-311	Side Block Rebuild Kit	1
510-450	O-ring*	1	525-745	Head Cushion Foam Spacer Kit	1
510-490	O-ring*	1	525-755	SL-27 Tri-Valve Exhaust Kit	1
510-504	Neck Dam, Neoprene, Medium	1	530-035	Screw	2
510-550	Oral Nasal Valve	1	530-045	Screw	1
510-575	Nose Block Pad	1	550-061	Spacer	2
510-683	Chin Cushion	1			
510-690	Oral Nasal Mask	1			

***See next page for O-ring Identification**

Equipment used for air diving or diving with oxygen mixtures containing **LESS than 40% oxygen** can be lubricated with food-grade silicone, such as Molykote® 111 or equivalent. DO NOT mix types of lubes in the regulators. At a minimum, all helmet or BandMask® O-rings should be replaced at least once a year in accordance with the A2.1 checklist for the helmet or mask being inspected. During daily and monthly maintenance, O-rings and valves may be reused if no damage or deformation is found. O-rings and valves may require replacement more often than yearly if helmet or mask use is extreme, or if the helmet or mask is used in waters containing oil or chemical contamination. Daily cleaning and inspections, as well as the monthly inspection (A2.2 checklist), will more accurately identify the need than simply counting hours between overhauls. Store spare O-rings, valves, and soft goods in a cool, dark, dry place. Avoid prolonged exposure to temperatures above 90 °F (32 °C) and/or to ultraviolet rays. Do not lubricate exhaust valves and diaphragms. Lubricating valves can cause dirt to adhere, leading to leakage.

⚠ CAUTION

Use only KMDSI original replacement parts. Using other manufacturers' parts will interfere with the performance of your life support equipment and may jeopardize your safety. Additionally, any substitutions will void any warranties offered by KMDSI. When ordering spares, always insist on Kirby Morgan Genuine Parts.



Kirby Morgan Dive Systems, Inc.®

1430 Jason Way Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.KirbyMorgan.com email: kmdsi@KirbyMorgan.com



510-008



510-010



510-029



510-490

NOT SHOWN

510-260 6.5" × 0.153"

1. Face Port O-ring

510-450 9" × 0.278"

1. Neck Ring O-ring

